






















### Glasurit® - Spot Repair Process

**Properties:**

In principle, this process is designed for the repair of smaller scratches and small stone chip damages or other cosmetic damages. For maximum cost effectiveness, the repair size/area should be kept as small as possible.

<b>Cleaning / polishing</b>	700-10 Glasurit® Degreasing and cleansing agent	 1 x	 wipe dry	Prepare the car parts for color retrieval by cleaning, polishing and removing small scratches.	 Standard polish	700-10 Glasurit® Degreasing and cleansing agent	 1 x	 wipe dry								
	<b>Preparation of damaged area</b>	Sand spot with orbital sander (75 mm) before body filler or primer filler application	 P240 - P400		700-1 Glasurit® Cleaner	 1 x	 wipe dry	<b>Body filler</b>	839-20 / 20K Glasurit® Multi Purpose Body Filler	948-36 Glasurit® Hardener Paste	 + 2-3%	 3-5 min.	 20-30 min. at 20°C	 P240 - P400	Clean surface with 700-10 Glasurit Degreasing and cleansing agent before applying 285-270.	 700-10 1x
<b>Primer filler application</b>		285-270 Glasurit® Primer Filler Pro, grey	929-58 Glasurit® HS Filler Hardener	352-50 Glasurit® Reducer	 4:1:1 wet on wet adjustment	 Mini HVLP spraygun 1.0 – 1.2 mm 1.0 – 1.5 bar	 1/2 +1 spraycoats 30-40 µm		 9 min.	<b>Sanding of primer filler / fade-out area</b>	Fine sanding with orbital sander (75 mm)	 P500 / P1000 - P3000	 700-1 1x	 wipe dry	<b>Basecoat (mixing ratio)</b>	90 Line Glasurit® Basecoat
	<b>Basecoat (mixing ratio)</b>	90 Line Glasurit® Basecoat	93-E3 Glasurit® Adjusting base	 2:1 mixing stick												

**Note:** Use Glasurit 839-90 Body Filler for repairs on plastic parts.

**Note:** Alternatively: 285-230 / -290 Glasurit Primer Filler Pro, white / black. For plastic parts, add 522-10 Glasurit plastic additive.  
Alternatively: 183-70 / -90 Glasurit 1K Express Primer Filler, light grey / dark grey
















**Safety advice:**

The products are suitable for professional use only.  
It cannot be ruled out that this product contains particles < 0.1 µm.

The data contained in this publication are based on our current knowledge and experience. In view of the many factors that may affect processing and application of our products, these data do not relieve processors from carrying out their own investigations and tests; neither do these data imply any guarantee of certain properties, nor the suitability of the products for a specific purpose. Any descriptions, drawings, photographs, data, proportions, weights etc. given herein are for general information purpose only; they may change without prior information and do not constitute the agreed contractual quality of the products (product specification). The latest version supersedes all previous versions. You can obtain the latest version from our website at <http://techinfo.glasurit.com> or directly from your sales partner. It is the responsibility of the recipient of our products to ensure that any proprietary rights and existing laws and legislation are observed.



## Glasurit® - Spot Repair Process

<b>Blending clear (mixing ratio)</b>	90-M50 Glasurit® Blending Clear	93-E3 Glasurit® Adjusting base	 2:1 mixing stick						
<b>Basecoat (mixture of 90 Line and 90-M50)</b>	90 Line Glasurit® Basecoat (ready for use)	90-M50 Glasurit® Blending Clear (ready for use)	 2:1 mixing stick	 Mini HVLP spraygun 1.0 – 1.2 mm 1.0 – 1.5 bar	 Spraycoats until covered	 flash off until matt between spraycoats and before clear			
<b>Note:</b> Apply and fade out 90 Line Glasurit Basecoat in thin, covering spraycoats.									
<b>Clear</b>	923-610 Glasurit® HS Clear fast-drying VOC	929-61 Glasurit® Hardener VOC fast	523-15 Glasurit® Racing Additive	 3:1:1 mixing stick	 Mini HVLP spraygun 1.0 – 1.2 mm 1.0 – 1.5 bar	 1/2 +1	 10 min.	or	 10 min. at 60°C
<b>Note:</b> Alternatively: 923-135									
352-500 Glasurit® Spot-Blender	 Mini HVLP spraygun 1.0 – 1.2 mm 1.0 – 1.5 bar	 Fade-out / polishing area	 8 min.	or	 15 min. at 60°C				
<b>Note:</b> Apply 352-500 Glasurit Spot Blender to the fade-out / polishing area to produce a smooth transition between the refinish clearcoat and the old paintwork.									
<b>Polishing</b>	Cool down before polishing	Polish the fade-out and the complete repair area with an appropriate polishing system	 Standard polish						

### Safety advice:

The products are suitable for professional use only.

It cannot be ruled out that this product contains particles < 0.1 µm.

The data contained in this publication are based on our current knowledge and experience. In view of the many factors that may affect processing and application of our products, these data do not relieve processors from carrying out their own investigations and tests; neither do these data imply any guarantee of certain properties, nor the suitability of the products for a specific purpose. Any descriptions, drawings, photographs, data, proportions, weights etc. given herein are for general information purpose only; they may change without prior information and do not constitute the agreed contractual quality of the products (product specification). The latest version supersedes all previous versions. You can obtain the latest version from our website at <http://techinfo.glasurit.com> or directly from your sales partner. It is the responsibility of the recipient of our products to ensure that any proprietary rights and existing laws and legislation are observed.

