

### Glasurit® Anti-silicone additive



**Application:** Used to avoid craters caused by silicones (wetting defects)

- Remarks:**
- Never add 580-100 inside the spray booth. Immediately remove cloths soiled with Antisilicone Additive
  - When you have used 580-100 Antisilicone Additive in the first coat, you must use it in all following coats as well (at least the same volume).
  - Do not use 580-100 in Glasurit VOC clears and 22 Line HS 2K Topcoat, VOC, 22 VOC MC600!

	<b>Paint system</b>	
	<b>Mixing ratio</b>	
	<b>Hardener</b>	
	<b>Reducer</b>	

**Safety advice:**

The products are suitable for professional use only.  
 It cannot be ruled out that this product contains particles < 0.1 µm.

The data contained in this publication are based on our current knowledge and experience. In view of the many factors that may affect processing and application of our products, these data do not relieve processors from carrying out their own investigations and tests; neither do these data imply any guarantee of certain properties, nor the suitability of the products for a specific purpose. Any descriptions, drawings, photographs, data, proportions, weights etc. given herein are for general information purpose only; they may change without prior information and do not constitute the agreed contractual quality of the products (product specification). The latest version supersedes all previous versions. You can obtain the latest version from our website at <http://techinfo.glasurit.com> or directly from your sales partner. It is the responsibility of the recipient of our products to ensure that any proprietary rights and existing laws and legislation are observed.

